

Single Port FXO Module for IP PBX and card





FXO

FXO is an interface that connects to a trunk line, like the one from your service provider. It receives ringing voltage and battery from FXS devices.FXO interfaces are used to connect your PBX to the PSTN. One FXO channel is required for each line your receive from your telco

AX-110X

AX-110X is an analog trunk module. It provides one channe FXO interface which allows the IPOX PBX and AX series card to terminate one analog telephone line to POTS.