

Indoor · 3-axis · Fixed Dome

**NETWORK CAMERA**

# Quick Installation Guide

English | 繁體中文 | 簡體中文 | 日本語 | Français | Español | Deutsch | Português | Italiano | Türkçe | Polski | Русский | Česky | Svenska | العربية



## FD7131

This guide describes the basic functions of FD7131.

All detailed information is described in the user's manual.



## Warning Before Install

- Power off the Network Camera as soon as it is found smoking or smelt unusual.



Contact your distributor when such cases happen.


- Do not place the Network Camera around the heat sources, such as television or oven.




- Keep the Network Camera away from direct sunlight.



- Do not place the Network Camera on unsteady surfaces.



- Do not disassemble the Network Camera.



- Do not insert any object into the Network Camera, such as needles.




- Keep the Network Camera away from the water. If the Network Camera is wet, power off immediately.




Contact your distributor when such cases happen.


- Refer to your user's manual for the operating temperature.




- Do not place the Network Camera in high humid environments.



- Do not touch the Network Camera when it's lightening.




- Do not drop the Network Camera.



# 1

## Package Contents

### FD7131




### Software CD




### Warranty card




### Screwdriver



### Power adapter




### Alignment sticker



### Quick installation guide






### Screws and I/O connector




## 2

## Physical Description



Drill holes  
Dome cover

Keep a note of the MAC address before installing the camera.




First, use the supplied screwdriver to detach the dome cover from the camera base. Then, follow the steps below to install the camera; either to a ceiling or to a wall.


### Installation Tips

Before installing the camera, look for a spot that best suits your needs. The built-in PIR sensor is designed to be triggered when a person enters its detection range. Therefore, it is crucial to install the camera at a place with the PIR sensor facing the desired direction. (The sensitivity of PIR sensor depends on object size and temperature differences between the object and the background environment.)

Top view



Side view




### Ceiling mount

Through the two holes on each side of the camera base, insert the supplied two screws to corresponding holes and secure them with a screwdriver.

### Wall mount

1. Attach the alignment sticker to the wall.
2. Through the two circles on the sticker, drill two pilot holes into the wall.
3. Hammer the supplied plastic anchors into the holes.
4. Align the two holes on each side of the camera base with the two plastic anchors on the wall, insert the supplied screws to corresponding holes and secure them with a screwdriver.




Alignment sticker

## 4 Network Deployment

### General Connection (without PoE)


1. If you have external devices such as sensors and alarms, make connections from general I/O terminal block.
2. Connect the camera to a switch via a Ethernet cable.
3. Connect the supplied power cable from the camera to a power outlet.



## **Power over Ethernet (PoE)**


### ● **When using a PoE-enabled switch**

The camera is PoE-compliant, allowing transmission of power and data via single Ethernet cable. See the following illustration to connect the camera to a PoE-enabled switch via Ethernet cable.




### ● **When using a non-PoE switch**

Use a PoE power injector (optional) to connect between the camera and a non-PoE switch.




## 5 Assigning IP Address

1. Install the "Installation Wizard 2" under the Software Utility directory from software CD.
2. The program will conduct analyses on your network environment. After your network is analyzed, please click on the "Next" button to continue the program.




3. The program will search the VIVOTEK Video Receivers, Video Servers or Network Cameras on the same LAN.
4. After searching, the main installer window will pop up. Click on the MAC that matches the one labeled on the bottom of your device to connect the Internet Explorer to the Network Camera.





1. Access to the Network Camera from the Internet.
2. Retrieve live video through web browsers or recording software.



For further setup, please refer to user's manual on the software CD.


## 7

## Adjusting the Lens

Based on the live image retrieved from the camera, adjust the camera lens by doing the following:


### **To adjust the viewing angle**

1. Loosen the pan screw and then turn the lens module left and right. Upon completion, tighten the pan screw.
2. Loosen the tilt screws on both side of the camera and then turn the lens module up and down. Upon completion, tighten the tilt screws.
3. Loosen the image adjustment screw and then turn the lens to adjust the image orientation. Upon completion, tighten the image adjustment screw.




### **To adjust the zoom factor and focus range**

1. Loosen the zoom controller and then adjust zoom factor by moving the controller left and right. Upon completion, tighten the zoom controller.
2. Loosen the focus controller and then adjust focus range by moving the controller left and right. Upon completion, tighten the focus controller.



DO NOT over tighten the controllers. Doing so would damage the structure of camera lens.

Attach the dome cover to camera. Secure the two dome screws with a screwdriver. Finally, make sure all parts of the camera are securely installed.



The supplied screwdriver is exclusively designed to match the dome screws. In case you will need to adjust the lens at a later time, do not discard the screwdriver.



P/N: 625003402G Ver.2.0  
Copyright © 2008 VIVOTEK INC. All right reserved.